

CHRYSAV**Introduction**

The CHRYSAV is designed to provide an audio/video input to the OEM overhead video screen from the aftermarket radio, and provide the audio/video input from the rear seat control panel to the aftermarket radio.

Note:

- The CHRYSAV is designed to work with the overhead video monitors that do not have the DVD player built in.
- This harness must be used in conjunction with the XSVI-6522-NAV, CHTO-03, or the CHTO-013.

APPLICATIONS**CHRYSLER**

Town & Country	2008-2012
----------------	-----------

DODGE

Durango	2011-2012
Grand Caravan	2012
Journey	2009-2010
Ram	2009-2012

JEEP

Grand Cherokee	2011-2012
----------------	-----------

CHRYSAV**Introduction**

The CHRYSAV is designed to provide an audio/video input to the OEM overhead video screen from the aftermarket radio, and provide the audio/video input from the rear seat control panel to the aftermarket radio.

Note:

- The CHRYSAV is designed to work with the overhead video monitors that do not have the DVD player built in.
- This harness must be used in conjunction with the XSVI-6522-NAV, CHTO-03, or the CHTO-013.

APPLICATIONS**CHRYSLER**

Town & Country	2008-2012
----------------	-----------

DODGE

Durango	2011-2012
Grand Caravan	2012
Journey	2009-2010
Ram	2009-2012

JEEP

Grand Cherokee	2011-2012
----------------	-----------

**1-800-221-0932****metraonline.com**

REV. 11/29/12 © COPYRIGHT 2004-2011 METRA ELECTRONICS CORPORATION

**1-800-221-0932****metraonline.com**

REV. 11/29/12 © COPYRIGHT 2004-2011 METRA ELECTRONICS CORPORATION

CHRYSAV**Introduction**

The CHRYSAV is designed to provide an audio/video input to the OEM overhead video screen from the aftermarket radio, and provide the audio/video input from the rear seat control panel to the aftermarket radio.

Note:

- The CHRYSAV is designed to work with the overhead video monitors that do not have the DVD player built in.
- This harness must be used in conjunction with the XSVI-6522-NAV, CHTO-03, or the CHTO-013.

APPLICATIONS**CHRYSLER**

Town & Country	2008-2012
----------------	-----------

DODGE

Durango	2011-2012
Grand Caravan	2012
Journey	2009-2010
Ram	2009-2012

JEEP

Grand Cherokee	2011-2012
----------------	-----------

CHRYSAV**Introduction**

The CHRYSAV is designed to provide an audio/video input to the OEM overhead video screen from the aftermarket radio, and provide the audio/video input from the rear seat control panel to the aftermarket radio.

Note:

- The CHRYSAV is designed to work with the overhead video monitors that do not have the DVD player built in.
- This harness must be used in conjunction with the XSVI-6522-NAV, CHTO-03, or the CHTO-013.

APPLICATIONS**CHRYSLER**

Town & Country	2008-2012
----------------	-----------

DODGE

Durango	2011-2012
Grand Caravan	2012
Journey	2009-2010
Ram	2009-2012

JEEP

Grand Cherokee	2011-2012
----------------	-----------

**1-800-221-0932****metraonline.com**

REV. 11/29/12 © COPYRIGHT 2004-2011 METRA ELECTRONICS CORPORATION

**1-800-221-0932****metraonline.com**

REV. 11/29/12 © COPYRIGHT 2004-2011 METRA ELECTRONICS CORPORATION

INTERFACE COMPONENTS

- 22-pin GMLAN RSE harness

TOOLS REQUIRED

- Cutting Tool • Tape • Crimping Tool
- Connectors (i.e. butt-connectors, bell caps, etc.)

INSTALLATION INSTRUCTIONS

Important: Before beginning any of the following, disconnect the negative battery terminal to prevent an accidental short circuit.

From the 22-pin harness

- Connect the "A/V 1" RCAs to the aftermarket radios audio/video input. Plug **Yellow** in to video-in, **Red** to right audio-in, and **White** to left audio-in.
- Connect the "A/V 2" RCAs to the aftermarket radios audio/video output. Plug **Yellow** in to video-out, **Red** to right audio-out, and **White** to left audio-out.
- Connect the **Yellow** RCA to the aftermarket radios backup camera input of the aftermarket radio.
- Connect the loose **Black** wire to ground.

INTERFACE COMPONENTS

- 22-pin GMLAN RSE harness

TOOLS REQUIRED

- Cutting Tool • Tape • Crimping Tool
- Connectors (i.e. butt-connectors, bell caps, etc.)

INSTALLATION INSTRUCTIONS

Important: Before beginning any of the following, disconnect the negative battery terminal to prevent an accidental short circuit.

From the 22-pin harness

- Connect the "A/V 1" RCAs to the aftermarket radios audio/video input. Plug **Yellow** in to video-in, **Red** to right audio-in, and **White** to left audio-in.
- Connect the "A/V 2" RCAs to the aftermarket radios audio/video output. Plug **Yellow** in to video-out, **Red** to right audio-out, and **White** to left audio-out.
- Connect the **Yellow** RCA to the aftermarket radios backup camera input of the aftermarket radio.
- Connect the loose **Black** wire to ground.



1-800-221-0932



metraonline.com

REV. 11/29/12

© COPYRIGHT 2004-2011 METRA ELECTRONICS CORPORATION



1-800-221-0932



metraonline.com

REV. 11/29/12

© COPYRIGHT 2004-2011 METRA ELECTRONICS CORPORATION

INTERFACE COMPONENTS

- 22-pin GMLAN RSE harness

TOOLS REQUIRED

- Cutting Tool • Tape • Crimping Tool
- Connectors (i.e. butt-connectors, bell caps, etc.)

INSTALLATION INSTRUCTIONS

Important: Before beginning any of the following, disconnect the negative battery terminal to prevent an accidental short circuit.

From the 22-pin harness

- Connect the "A/V 1" RCAs to the aftermarket radios audio/video input. Plug **Yellow** in to video-in, **Red** to right audio-in, and **White** to left audio-in.
- Connect the "A/V 2" RCAs to the aftermarket radios audio/video output. Plug **Yellow** in to video-out, **Red** to right audio-out, and **White** to left audio-out.
- Connect the **Yellow** RCA to the aftermarket radios backup camera input of the aftermarket radio.
- Connect the loose **Black** wire to ground.

INTERFACE COMPONENTS

- 22-pin GMLAN RSE harness

TOOLS REQUIRED

- Cutting Tool • Tape • Crimping Tool
- Connectors (i.e. butt-connectors, bell caps, etc.)

INSTALLATION INSTRUCTIONS

Important: Before beginning any of the following, disconnect the negative battery terminal to prevent an accidental short circuit.

From the 22-pin harness

- Connect the "A/V 1" RCAs to the aftermarket radios audio/video input. Plug **Yellow** in to video-in, **Red** to right audio-in, and **White** to left audio-in.
- Connect the "A/V 2" RCAs to the aftermarket radios audio/video output. Plug **Yellow** in to video-out, **Red** to right audio-out, and **White** to left audio-out.
- Connect the **Yellow** RCA to the aftermarket radios backup camera input of the aftermarket radio.
- Connect the loose **Black** wire to ground.



1-800-221-0932



metraonline.com

REV. 11/29/12

© COPYRIGHT 2004-2011 METRA ELECTRONICS CORPORATION



1-800-221-0932



metraonline.com

REV. 11/29/12

© COPYRIGHT 2004-2011 METRA ELECTRONICS CORPORATION